


Handling your Yealink T46S

Maximum compatibility and flexibility with the MIXpbx.



Legend

- 1 : Screen
- 2 : Power indicator LED
- 3 : Programmable keys
- 4 : Mute key and headset
- 5 : Action keys
- 6 : Speaker
- 7 : Volume
- 8 : Keypad
- 9 : Menu and directional pad
- 10 : Four action keys

Action keys handset hung up

- 1** : FWD = forward
- 2** : DND = do not disturb
- 3** : Phonebook
- 4** : Menu

Action keys during a phone call

- 1** : Transfer
- 2** : Hold
- 3** : Conference
- 4** : End call


Action keys incoming call

- 1** : Answer
- 2** : FWD = forward
- 3** : Silence
- 4** : Reject

my personal notes

Handling your Yealink T46S

Maximum compatibility and flexibility with the MIXpbx.



my personal notes

Place a call

Enter the number, and press **OK** in the centre of the direction pad

Transfer a call

Blind transfer:

- Press on **[Transfer]** or on the action key "transfer" **1** The call is on hold.
- Enter the destination extension number, then hang up.

Attended transfer:

- Press on **[Transfer]** or on the action key "transfer" **1** The call is on hold.
- Enter the destination extension number, then press on **OK**
- Press again on **[Transfer]** to transfer the call
- If the person doesn't wish to take the call, press on **4** then "hold" **[Hold]** to take it back.
- If you receive a second call while the first one is on hold, you can select the call to transfer with the directional pad and instructions on the screen.

Call interception (if activated)

If the phone of a colleague is ringing, and you want to intercept the call, press key **1** "DPickup", or enter the number of the ringing extension.

Enable a call forward

Press on action key "Forward" **1**, then twice on "Enter" **4**. Navigate with the right arrow on the directional pad, select "enable" and input the destination number on the second line "forward to" (internal or external number), then save with the key "save" **4**. To disable the call forward, follow the same path but choose the "disable" option.

Place a call on hold

To place a call on hold, press the key "hold" **[Hold]**. To resume the call, press "hold" again. When a first call is on hold, you can initiate a second call with the key **3** "new call". When you take a second line, the first conversation is automatically placed on hold. Press on **2** "swap" to allow you to switch from one conversation to another one.

Call conference

During an active call you can welcome a third person into the conversation. Press "conf" **3** then enter the number (internal or external), then press again on "conf" **3**. All parties are joined in the conference.

Call log

Press on "redial" **[Redial]** to access the call history and missed calls, or "Message" to access voice messages. Use the directional pad to choose between the different options.

Change the ring tone

Access the menu by pressing **OK**. Then "basic", "sound" and "ring tone", then "save" **4** to validate your choice.